


# LoRa Device

**Note:** This guide is intended for use with LoRa's with a digital display only.





## MAIN DISPLAY IN LORA RADIO MODE



## SET TO LORA RADIO MODE

All LoRa's must be set to Radio mode to work with GivEnergy inverters.  
Use the buttons on the front of both LoRa's, one at a time.



1. Press and hold **FUNC** to display the Main Menu



2. Press **FUNC** repeatedly to scroll to System



3. Press **ENTER** to select System Setting menu



4. Press **ENTER** repeatedly until display reads LoRa Radio



5. Press **FUNC** to return to Main Menu




6. Press **FUNC** to scroll to Reboot



7. Press **ENTER** to reboot device to update settings

## CHANGE RADIO FREQUENCY

All LoRa's must be set to Radio mode to work with GivEnergy inverters.  
Use the buttons on the front of both LoRa's, one at a time.



1. Press and hold **FUNC** to display the Main Menu



2. Press **FUNC** repeatedly to scroll to Frequency



3. Press **ENTER** to select Frequency Setting menu



4. Press **FUNC** to select digit to change



5. Press **ENTER** to Increase digit



6. Press **FUNC** to scroll to Reboot



7. Press **ENTER** to reboot device to update settings

Modules must be on the same frequency to communicate with each other

## CHANGE SERIAL PORT SETTINGS

In some cases the port that the LoRa communicates with the inverter and battery on may need configuration. Using buttons on the front of **both** LoRa's at one time.

```
--- Setting ---  
Serial Saud Rate  
[9600 bps]
```

```
--- Setting ---  
Serial Parity  
[None]
```

```
--- Setting ---  
Restart System  
[Cancel] [OK]
```



1. Press and hold **FUNC** to display the Main Menu



2. Press **FUNC** repeatedly to scroll to UART



3. Press **ENTER** to select UART Setting menu



4. Press **ENTER** repeatedly to scroll to desired Baud Rate



5. Press **FUNC** to Parity.sub menu



6. Press **ENTER** repeatedly to scroll to desired Parity



7. Press **FUNC** to reboot device to update settings



8. Press **FUNC** to scroll to Reboot



9. Press **ENTER** to reboot device to update settings